www.groomix.com

USER MANUAL

TIMELY ANNOUCEMENT SYSTEM

Model:GX-TAS60SD

SCAN FOR WEBSITE

DOWNLOADS

YOUTUBE DEMO

GROOMIX ENTERPRISES
Brand For Quality Living

GSTN: 09AWCPN5078M1ZW, **Mobile:** +91-9125110098, **Email:** info@groomix.com, **Website1:** www.groomix.com, **Website2:** www.groomix.in
Address: Shop No. 1, 537GHA/498, Arzoo Nagar, Mohibullapur, Lucknow-226021, Uttar Pradesh, INDIA

TAS60SD	DATASHEET	04/05/2026

(Supported Models: GX- TAS60SD V8.0)

SCAN FOR WEBSITE

YOUTUBE DEMO


TIMELY ANNOUNCEMENT SYSTEM(TAS60SD)

Features:

- High precision clock chip with inbuilt battery
- Electronically generated Gong Bell sound which make it robust and highly durable
- 15 clock time can be set separately for any day of the week
- 15 clock time can be set for allday which will ring every day of the week
- Inbuilt audio amplifier of 60W(30W + 30W)
- Support 8-ohm speakers

SETTINGS

Customer support:
+91-9125110098
Timing: 10am – 6pm



Press “SETTING” to start settings
press “UP” and “DOWN” to change values or setting options, press and hold to change value faster.
press “OK” to select or to go to next setting, press “OK” to one second to go back and press “OK” for 5 second to skip editing bell to +5 bell setting.
Press “SETTING” to exit from settings

1) Setting (max 15 Schedules per day):







This will set schedule on SUNDAY which will ring only on SUNDAY days.
Press “setting” it will display setting list and select “SUNDAY BELL” using “UP” and “DOWN” button and then press “OK” to edit “SUNDAY BELL” settings. First value is hour in 24hr format. Press “OK” to Second value which is minute value. Third value is the CODE of audio list. Forth value is the number of repetition of same audio. Set here the number of times you want to ring sing bell. Put value “0” if don’t want any of the bell type “multiple” or “single” bell. Press “OK” to set next bell setting out of 30 bells. If you don’t and any of the bell, keep it HH=24 MM=00 CODE=00 REP=00. The number at top-left is indicate which you are setting out of 15 schedules bell options.

2) Setting for Allday (max 15 Schedules for Allday):









Allday setting is same as particular day setting. Allday bell will announce everyday

3) System Clock




This is the current time of system. Make change only if system time is not synchronized with clock. Press “setting” and scroll to “6) System Clock” option and press “OK”. Change the value of hours and minutes and press “OK”. Press “SETTING” to exit without changing time.

4) System Date



Update system date to current date. Use “UP”, “DOWN” and “OK” buttons to edit.

5) System Day



Update system day to current day. Use “UP”, “DOWN” and “OK” buttons to edit.

SCAN FOR WEBSITE

YOUTUBE DEMO

Customer support:
+91-9125110098
Timing: 10am – 6pm

Connection diagram

Customer support:
+91-9125110098
Timing: 10am – 6pm



Note: This product image is only for illustration of connections. Real product may be different from it